

## **SPARK-PROOF URETHANE CHOCKS CAUTIONS:**

1. **For use on flat track only.**  
Do not use chocks on grades.
2. **Set brakes before installing chocks.** Rail car or locomotive must be stopped and brakes applied **before** chocks can be placed.
3. Do not use chock if rail car or locomotive is lifted up at one end for inspection or repair.
4. **Use rubber cord** as supplied to keep chocks tight against wheel (double chocks).
5. **Chock both ends** of the rail car or locomotive.
6. Use only on rails 90 to 155 lbs./yd.
7. For wheel diameters 26" - 48".
8. **Do not use on oily or greasy rail** as chock will slide.
9. When rail car is ready to be moved, you may pull car over chocks. They will return to their original shape.
10. Replace chocks if urethane is torn or cracked.